

LS-16096

SCART ADAPTER SCATR PLUG TO 3xRCA AND S-VHS JACKS WITH SWITCH



LS-16097

SCART ADAPTER SCATR PLUG TO 3xRCA AND S-VHS JACKS WITH SWITCH



LS-16098

21 PIN SCART PLUG TO RCA PLUG



LS-16099

21 PIN SCART PLUG TO RCA JACK




LS-16100

21 PIN SCART PLUG TO 2 RCA JACKS W/SWITCH



LS-16101

21 PIN SCART PLUG TO 3 RCA JACKS W/SWITCH




LS-16102

21 PIN SCART PLUG TO 3 RCA JACKS AND 1 MINI 4 PIN JACK-IN




LS-16103

21 PIN SCART PLUG TO 3 RCA JACKS AND 1 MINI 4 PIN JACK-OUT




LS-16104

21 PIN SCART PLUG TO 3 RCA JACKS AND 1 MINI 4 PIN JACK W/SWITCH



LS-16105(GOLD METAL)

21 PIN SCART PLUG TO 3 RCA JACKS AND 1 MINI 4 PIN JACK W/SWITCH



LS-16106

SCART PLUG TO 3RCA JACKS OUT



LS-16107

SCART PLUG TO 3 RCA JACKS IN



LESEN SCART CONNECTOR

LS-16108

21 PIN SCART PLUG TO
21 PIN SCART JACK AND
2 RCA JACKS
W/SWITCH



LS-16109

21 PIN SCART PLUG TO
21 PIN SCART JACK AND
3 RCA JACKS
W/SWITCH



LS-16110

SCART PLUG TO SCART
JACK WITH 3RCA JACKS
AND MINI 4PIN JACK




LS-16111

SCART PLUG TO SCART
JACK WITH 3 RCA JACKS
(IN OR OUT)



LS-16112

SCART JACKS BOX




LS-16113

21 PIN SCART JACK TO
21 PIN SCART JACK



LS-16114

21 PIN SCART
PLUG TO 21
PIN SCART
JACK AND 3.5MM
STEREO JACK



LS-16115

SCART PLUG TO
2RCA JACKS
(IN OR OUT)



LS-16116

SCART PLUG TO
3RCA JACKS
(IN OR OUT)




LS-16117

AV-SWITCH S[VHS]



LS-16118

AUDIO-VIDEO CONTROL
CENTRE



LS-16119

